

Technical Bulletin

W E K N O W T H E R O A D™

X-C 6250 Computer Vehicle Cradle

The Vehicle Cradle has been designed to allow easy, one-handed installation of the X-C 6250 computer.

IMPORTANT Cradle components can be damaged if the computer is improperly installed. Follow these recommended installation procedures to prevent possible cradle failure.

To install the computer onto the cradle

- 1 With the display closed over the keyboard, slide your working hand between the handle and the computer so that the handle is on top of your hand and your palm and fingers can grasp the computer.
- 2 Grasping the computer with your working hand, tilt the computer backward slightly toward the cradle latch (A), and then center the slot on the front of the computer over the dovetail pivot (B).
- 3 Move the computer forward so the dovetail pivot is completely in the slot.
The dovetail will pivot back toward the cradle latch.
- 4 Verify that the computer and dovetail pivot are properly engaged by rocking the computer side to side.
You will not be able to rock the computer at all if it is installed correctly; the dovetail pivot will stop this motion completely.
- 5 Slide your hand out from under the handle, and then press the unit down to latch it into place (C).
- 6 Press the vehicle cradle's power button to turn it on.

The computer has been installed onto the cradle correctly if the external power light on the computer is solid or flashing.

